




N°	Code	HV		A	B	$\longleftrightarrow$	$\updownarrow$
7024-AA	<b>B</b> <sub>JET</sub>	230 HV	65 %	0.30	0.25	125 mm	10 mm
7025-AA	<b>B</b> <sub>XEL</sub>	280 HV	95 %	0.30	0.25	125 mm	10 mm
7026-AA	<b>B</b> <sub>z</sub>	230 HV	80 %	0.30	0.25	125 mm	10 mm
7027-AA	<b>B</b> <sub>VOX</sub>	700 HV	0 %	0.30	0.25	125 mm	10 mm
7028-AA	<b>B</b> <sub>*</sub>	290 HV	100 %	0.30	0.25	125 mm	10 mm



N°	Code	HV		A	B	$\longleftrightarrow$	$\updownarrow$
7026-F	<b>B</b> <sub>z</sub>	230 HV	80 %	0.08	1.70	120 mm	10 mm
7027-F	<b>B</b> <sub>VOX</sub>	700 HV	0 %	0.08	1.70	120 mm	10 mm
7027-PM-F	<b>B</b> <sub>VOX</sub>	700 HV	0 %	0.08	1.70	120 mm	10 mm
7028-F	<b>B</b> <sub>*</sub>	290 HV	100 %	0.08	1.70	120 mm	10 mm